

Alzheimer's currently affects around 850,000 individuals in the UK with approximately 210,000 people contracting dementia per year as well as this, people above the ages of 80 have been found to have a 1 in 6 chance of having the disease. Dementia encompasses of various brain disorders that cause a deterioration of brain function. All of these conditions being generally gradual though and ultimately severe. Dementia symptoms include memory loss, confusion and problems with speech and comprehension problems and is a terminal condition. Overall treatment and care expenses in the UK alone has cost around £35 billion (Alzheimer's Society, 2020)

Alzheimer's has been identified to correlate with protein A β containing a glycine zipper motif, in which is deemed have an important role in the tissue formation of amyloid fibril formation which is thought to have a toxic pathogenic effect (Fonte, 2011).

Using a custom regex of (G|A)...(G)...(T|G) these stronger and weaker membrane proteins in which the motif is commonly found in can be used to search through Uniprot accession codes to find the matching motifs.


This regex expression for checking motifs was generated using the Espresso program, which provides a toolbox that enables a user to construct regular expressions using a collection of tabs from which you can pick all of the syntactical components desired. Test data may be interpreted or entered manually after creating an expression, and the standard expression can be performed against the data after which the search results are then shown (Ultrapico, 2010).

The tool utilises python due to being a relatively easy to learn programming language due to the syntax being easy to read and having a large community leading to lots of resources to be used meaning it can be used to solve a range of problems.

The program utilises Biopython a open source python library with functions for reading and writing various sequence file formats and sequence alignments within batches as well as being able to access key online databases such as SwissProt (Cock, 2009).


User Guide

Step 1: Folder Unzipping




The first step after downloading the zip file containing the search tool would be to extract the zip folder this could be done through any extracting program for example 7zip.

Step 2: Opening Python file




Once installed you will want to run the extracted .py file and run it either through the command prompt for ease of use through Visual Studio Code

Step 3: Executing Python File



After opening file hover over the run button on the top of the application and then click 'Run Without Debugging' or press Ctrl+F5

Step 4: Inputting Accession codes



After clicking run this tool will open up on your screen with instructions to insert your desired accession codes into the text box this can be either one or multiple accession codes though must be separated by a delimiter in this case being ','

Step 5: Finding Corresponding Motifs

Once desired Accession codes have been inserted click the 'Find Motif' which will then print the motifs found in the box below.

The screenshot shows the 'Alzheimer's Amyloid Motif Detection Tool' window. At the top, a text box prompts the user to 'Input UniProt accession code below as comma seperated e.g. P012345,P012345:'. Below this, a text input field contains the accession codes 'P10636,P10997,P04156,P05067,P02647'. A red arrow points to this input field. Below the input field is a 'Find Motif' button, also indicated by a red arrow. At the bottom, there is a large, empty text area for displaying results.

Step 6: View Results

The screenshot shows the same tool window, but now the 'Find Motif' button has been clicked. The results are displayed in the bottom text area. The results for P10636 are as follows:

```
P10636
sequence: AEEAGIGDT
start: 102
end: 111
AT rich region from 102 to 111
sequence: GPSVGRAKG
start: 285
end: 294
AT rich region from 285 to 294
-----
P10997
No matches found
```

Red arrows point to the first and second entries in the results list.

Printed results for Motifs found will be shown in the box where the user can freely scroll through analysing the Accession code as well as the sequence, start and end of motif as well as informing the user of where in the sequence this match can be found. If a match isn't found then the user will get a response of No matches found.

Alzheimer's Amyloid Motif Detection Tool

Input UniProt accession code below as comma seperated e.g. P012345,P012345:

P10636

Find Motif

P10636
sequence: AEEAGIGDT
start: 102
end: 111
AT rich region from 102 to 111
sequence: GPSVGRAKG
start: 285
end: 294
AT rich region from 285 to 294

Any previous results will automatically be cleared if new accession codes are entered on button press of the 'Find Motif'

Alzheimer's Amyloid Motif Detection Tool

Input UniProt accession code below as comma seperated e.g. P012345,P012345:

eqwe

Find Motif

If an accession code isn't inputted then no results on to whether a match was found or not will not be displayed.

Appendix

```
from Bio import SeqIO
from Bio import ExPASy
from Bio import SwissProt
from tkinter import *
from tkinter import scrolledtext
import tkinter as tk
import re

def inspectArrangement(): #Method for user to input accession codes
    sct_result.delete('1.0', END)
    accession_codes = txt_input_field.get("1.0",'end-1c') #Stores user input into accession_codes
    accession_codes = accession_codes.replace(" ","")#Validation to remove spaces
    accession_codes = accession_codes.split(",") #splits all inputted accession codes
    for accession_code in accession_codes: #for every found accession code within the codes
        sequence = sequenceRetrival(accession_code) #run the sequenceRetrival function and assign the
        # returned value to the sequence variable
        matchFinder(sequence, accession_code)#runs the matchfinder function with the sequence found

def sequenceRetrival(accession_code): #Method to retrieve sequence from accession codes
    handle = ExPASy.get_sprot_raw(accession_code)
    record = SwissProt.read(handle)
    handle.close()
    sequence = record.sequence
    return sequence

def matchFinder(sequence, accession_code): #Method to inspect matches within each sequence
    matchs = re.finditer("(G|A)...(G)...(T|G)",str(sequence)) # Finds the matched regex within each fasta
    sct_result.insert(INSERT, accession_code + "\n")
```

```

count = 0

if matches:

    for match in matches:

        matchs_start = match.start()

        matchs_end = match.end()

        matchs_group = match.group()

        sct_result.insert(INSERT, "sequence: " + str(matchs_group) + "\n")

        sct_result.insert(INSERT, "start: " + str(matchs_start) + "\n")

        sct_result.insert(INSERT, "end: " + str(matchs_end) + "\n")

        sct_result.insert(INSERT, "AT rich region from " + str(matchs_start) + " to " + str(matchs_end
)+ "\n")

        count +=1

if count == 0: # if matches are empty responds with no matches found

    sct_result.insert(INSERT, "No matches found \n")

sct_result.insert(INSERT, "----- \n")

if __name__ == '__main__': # Entry point for application

    window = tk.Tk() #Creates tkinter object


    window.title("Alzheimer's Amyloid Motif Detection Tool") # Setting up window and name

    window.geometry('750x500')

    window.configure(background = 'Grey')

    window.resizable(width=FALSE, height=FALSE)


    background_image = PhotoImage(file="background.png")

    background_label = Label(window, image=background_image)

    background_label.place(x=0,y=0, relwidth=1, relheight=1)


    lbl_instruction = Label(window, text="Input UniProt accession code below as comma seperated
e.g. P012345,P012345:", font = ('articalat',13,'bold')) #Creates and places instruction label

    lbl_instruction.grid(column=0, row=1, padx=40, pady=10)

```



```
txt_input_field = Text(window) #Creates and places input field
txt_input_field.grid(column=0, row=2, padx=40, pady=10, sticky="W")
txt_input_field.config(width=80, height = 6)

sct_result = scrolledtext.ScrolledText(window) #Creates and places result field
sct_result.grid(column=0, row=4, padx=40, pady=10, sticky="W")
sct_result.config(width=80, height=12)

btn_run = Button(window, width=93, text="Find Motif", command=inspectArrangement) #Creates and places button and binds it to inspect arrangement method
btn_run.grid(column=0, row=3, padx=0, pady=10)
btn_run.config(width=64)

window.mainloop() #Stops the window from closing
```

References

1. Alzheimer's Society,(2020).*Facts for the media*
2. Fonte, V., Dostal, V., Roberts, C. M., Gonzales, P., Lacor, P., Magrane, J., ... & Link, C. D. (2011). *A glycine zipper motif mediates the formation of toxic β -amyloid oligomers in vitro and in vivo. Molecular neurodegeneration.*
3. Ultrapico.(2010). *Expresso 3.1*
4. Cock, P. J., Antao, T., Chang, J. T., Chapman, B. A., Cox, C. J., Dalke, A., ... & De Hoon, M. J. (2009). Biopython: freely available Python tools for computational molecular biology and bioinformatics. *Bioinformatics*, 25(11), 1422-1423.